

FTERO DL 650/DL 1000 Instructions

1. Ensure that you have all the necessary mounting screws, screw caps, drill bit,



2. mounting bracket

3. and TORX security bit T20 (might be different than pictured).



4. You will need to provide your own 12mm wrench and drill.



5. Place FTERO in place



6. Note the tabs on the rear side and make sure they are placed on the edge of the wheel fender.

7. Using your drill and the supplied drill bit, drill the 3 holes in the fender. Make sure the screws can be fully inserted.



8. Use the supplied mounting bracket on the inside of the fender and screw all 3 screws tightly. **You do not need to use the screw caps if you use the mounting bracket.**



9. If your drilled holes don't match or you prefer an easier installation instead of the mounting bracket you can just use the supplied screw caps to support the screws.

10. Congratulations!



If you have any questions, please contact us at sales@motoagora.com