

PODIA DL1000

Instructions

1. Unscrew the bolts in the middle bracket and insert the locking washers included in the package on the bolts.



2. Re-Screw the bolts a little. The bracket needs to be loose, it will be the last bolts to tighten.
3. Attach the skid-plate to the motorcycle using all the other bolts. The mounting points should be obvious after aligning the skid-plate.
4. Tighten the middle bracket being careful not to make contact with the exhaust pipe.